

# Assignment 2

Advanced Flight Mechanics 2021-22

Eduardo Andrés  
Abolfazl Simorgh

# A2. Navigation


- Session 1: Sensors
- Session 2: Kalman Filter

# Session 1


Sensors

# 1. Introduction and objectives

- Implement the linear model in Simulink
  - You will only need  $A_{long}$  and  $A_{lat}$  from Assignment1.
  - Excite the Phugoid and the Dutch Roll.
- Get measures from a 3-axis gyroscope.



- Filter the outputs with a Kalman Filter.



- Compare the ideal, the measured and the filtered angular rates.

## 2. Linear model (I)

One model for longitudinal and lateral dynamics.

- Dynamics  $\dot{\mathbf{x}} = A\mathbf{x}$
- Output  $\mathbf{y} = C\mathbf{x}$

Such that:

- $\mathbf{x} = [u \ w \ q \ \theta \ v \ p \ r \ \psi]^T$
- $\mathbf{y} = [p \ q \ r]^T$


Then

$$A = \begin{bmatrix} A_{long} & 0_{4 \times 4} \\ 0_{4 \times 4} & A_{lat} \end{bmatrix}$$

$$C = \begin{bmatrix} 0 & 0 & 0 & 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 1 & 0 \end{bmatrix}$$

## 2. Linear model (II)

In Simulink




‘Linear Dynamics’ block

### 3. Gyroscope


- From the linear model:

- $\omega = \mathbf{y} = [p \ q \ r]^T$
- $G's = \frac{1}{g} [\dot{u} \ \dot{v} \ \dot{w}]^T$






'Ideal/Real Output' block

- Gyroscope settings:
  - In 'main', first order dynamics.
  - In 'noise', *noise power* =  $(10^{-6}, 10^{-6}, 10^{-6})$



## 4. Kalman Filter





## 5. Tips for Simulink

- Always run the model from Matlab.
- Do not include numerical values inside Simulink blocks. Use variables from your Matlab workspace. It is easier to assign values from there.
- Be careful with vectors, maybe you need a column instead of a row.
- Use 'ToWorkspace' block to export results to Matlab and work with them.

Matlab Code:

```
out = sim('model', t);  
time = out.tout;  
p_real = out.sensor.Data(:, 1);  
q_real = out.sensor.Data(:, 2);  
r_real = out.sensor.Data(:, 3);
```