


# Aerodynamic forces and Moments

①



$P = P(s)$  = surface pressure distribution

$\tau = \tau(s)$  = surface shear stress distribution

+  $L = \text{Lift} \equiv$  Component of  $R$  perpendicular to  $V_{\infty}$

$D = \text{Drag} \equiv$  Component of  $R$  parallel to  $V_{\infty}$

+  $N = \text{normal force} \equiv$  component of  $R$  perpendicular to  $C$

$A = \text{Axial force} =$  component of  $R$  parallel to  $C$

$$L = N \cos \alpha - A \sin \alpha$$



$$D = N \sin \alpha + A \cos \alpha$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70



Upper

$$dN'_u = -P_u ds_u \cos \theta - \tau_u ds_u \sin \theta$$

$$dA'_u = -P_u ds_u \cdot \sin \theta + \tau_u ds_u \cos \theta$$

Lower

$$dN'_l = P_l ds_l \cos \theta - \tau_l ds_l \sin \theta$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70



The total normal and axial forces per unit span

$$N' = - \int_{LE}^{TE} (P_u \cos \theta + \bar{t}_u \sin \theta) ds_u + \int_{LE}^{TE} (P_L \cos \theta - \bar{t}_L \sin \theta) ds_L$$

$$A' = \int_{LE}^{TE} (-P_u \sin \theta + \bar{t}_u \cos \theta) ds_u + \int_{LE}^{TE} (P_L \sin \theta - \bar{t}_L \cos \theta) ds_L$$

L and D are obtained replacing N' and A'

The aerodynamic moment exerted on the body depends on the point about which moments are taken.



Convention moments.

Increase  $\alpha$  (pitch up)  
 If it is positive (pitch down)  
 decrease  $\alpha$

Upper

$$dM'_u = (P_u \cos \theta + \bar{t}_u \sin \theta) x ds_u + (-P_u \sin \theta + \bar{t}_u \cos \theta) y ds_u$$

Lower

$$dM'_l = (-P_L \cos \theta + \bar{t}_L \sin \theta) x ds_L + (P_L \sin \theta + \bar{t}_L \cos \theta) y ds_L$$



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP: 689 45 44 70

$$M'_{LE} = \int_{LE}^{TE} [(P_u \cos \theta + \tau_u \sin \theta)x - (P_u \sin \theta - \tau_u \cos \theta)y] ds_u$$


$$+ \int_{LE}^{TE} [(-P_l \cos \theta + \tau_l \sin \theta)x + (P_l \sin \theta + \tau_l \cos \theta)y] ds_l$$

The equations and  $\theta$ ,  $x$ , and  $y$  are known functions of  $s$  for a given body shape. Hence, if  $P_u$ ,  $P_l$ ,  $\tau_u$  and  $\tau_l$  are known as functions of  $s$ .

The sources of the aerodynamics lift, drag and moments on a body are pressure and shear stress distributions integrated over the body.

A Major goal of theoretical aerodynamics is to calculate  $P(s)$  and  $\tau(s)$  for a given body shape and freestream conditions, thus yielding the aerodynamic forces and moments.

- Geometrical relationship of differential lengths



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

Cartagena99

$$C_n = \frac{1}{C} \int_0^c (C_{pL} - C_{pu}) dx + \int_0^c (C_{fu} \frac{dy_u}{dx} + C_{fL} \frac{dy_L}{dx}) dx \quad (2)$$

$$C_a = \frac{1}{C} \int_0^c (C_{pu} \frac{dy_u}{dx} - C_{pL} \frac{dy_L}{dx}) dx + \int_0^c (C_{fu} + C_{fL}) dx$$

$$C_{mLE} = \frac{1}{C^2} \left[ \int_0^c (C_{pu} - C_{pL}) x dx - \int_0^c (C_{fu} \frac{dy_u}{dx} + C_{fL} \frac{dy_L}{dx}) x dx \right. \\ \left. + \int_0^c (C_{pu} \frac{dy_u}{dx} + C_{fu}) y_u dx + \int_0^c (-C_{pL} \frac{dy_L}{dx} + C_{fL}) y_L dx \right]$$

$$C_L = C_n \cos d - C_a \sin d$$

$$C_d = C_n \sin d + C_a \cos d$$

**Cartagena99**

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

The logo for Cartagena99 features the text 'Cartagena99' in a stylized, blue, serif font. The text is set against a light blue, arrow-shaped background that points to the right. Below the text, there is a horizontal orange bar with a slight gradient, giving the logo a three-dimensional appearance.


**CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70**

---

**ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP:689 45 44 70**



→  
d Decreasing.



Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP:689 45 44 70

$$\frac{L}{D} = \frac{\rho_{\infty} S C_L}{\rho_{\infty} S C_D} = \frac{C_L}{C_D}$$

$C_L$  for flying at a given velocity and altitude is determined by airplane's weight and wing area  $\left(\frac{W}{S}\right)$  wind loading

The relation  $C_L \propto \frac{L}{\rho_{\infty} S} = \frac{W}{\rho_{\infty} S}$ , so the value of  $\frac{L}{D}$  at this velocity is controlled by  $C_D$ .

For any velocity, we need to get  $\frac{L}{D}$  to be as high as possible. The higher is  $\frac{L}{D}$  the more aerodynamically efficient is the body.



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

Cartagena99



# Center of Pressure

Equations for normal and axial forces on the body are due to the distributed loads imposed by pressure and shear stress distribution. These loads generate a moment about the leading edge as given by the equation of moment.



(+) Pitching moment

$N'$  creates a negative moment about the LE. (Pitching down)

$$M_{LE}' = -(x_{cp}) N'$$

$$x_{cp} = - \frac{M_{LE}'}{N'}$$

(It is defined as the Cp. It is the location where the resultant of a distributed load effectively acts on the body.)

If the moments were taken about the C.P., the integrated effect of the distributed loads would be zero. Another definition is that point on the body

**CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70**

---




**ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70**

**Cartagena99**

If the case where the angle of attack of the body is small  $\sin \alpha \approx 0$  and  $\cos \alpha \approx 1$  then

$L' = D'$  thus  $x_{cp} = -\frac{M'_{LE}}{L'}$   $x_{cp}$  increases when  $L'$  and  $N'$  decreases.

If the forces approach zero, the  $cp$  moves to infinity. (No always is a convenient concept in aerodynamics)



$$\left[ M'_{LE} = -\frac{c}{4} L' + M'_{c/4} = -x_{cp} L' \right]$$

Solution problem 3.

$$\begin{aligned} \frac{c}{4} L' &= M'_{c/4} - M'_{LE} = -4850 - (-14550) \\ &= 9700 \text{ N.m/m} \end{aligned}$$

At this airfoil location on the wing  $\frac{c}{4} = \frac{4.6}{4} = 1.15\text{m}$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

# Review Algebra

Consider a vector field


$$A = A(x, y, z) = A(r, \theta, z) = A(r, \theta, \phi)$$

Also consider a curve C in space connecting two points a and b



$\vec{n}$  = unit vector tangential  
 $ds$  = elemental length  
 $d\vec{s} = n ds$  vector

$$\int_a^b A \cdot ds$$



$$\oint_C A \cdot ds \quad \text{closed C.}$$

Surface integrals



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP: 689 45 44 70


We define a vector elemental area  $d\mathbf{s} = \mathbf{n} ds$

$\iint_S P ds =$  surface integral of a scalar  $P$  over the open surface  $S$ . (Result is a scalar)

$\iint_S \mathbf{A} \cdot d\mathbf{s} =$  surface integral of a vector  $\mathbf{A}$  over the open surface  $S$  (Result is a scalar)

$\iint_S \mathbf{A} \times d\mathbf{s} =$  surface integral of a vector  $\mathbf{A}$  over the open surface  $S$  (Result is a vector)

If the surface is closed



$$\oiint P ds \quad \oiint \mathbf{A} \cdot d\mathbf{s} \quad \oiint \mathbf{A} \times d\mathbf{s}$$

## Volume Integral

Consider a volume  $V$  in space. Let  $\rho$  be a scalar field in this space the volume integral is

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

Cartagena99

Let  $A$  be a vector field in space. The volume integral over the volume  $V$  of the quantity  $A$  (7)

$$\iiint_V A \cdot dV = \text{Volume integral of a vector } A \text{ over the volume } V \text{ (Result is a vector)}$$

Relation Between Line, Surface and Volume integrals

$$\oint_C A \cdot ds = \iint_S (\nabla \times A) \cdot ds \Rightarrow$$

Let  $A$  be a vector field. The line integral of  $A$  over  $C$  is related to surface integral of  $A$  over  $S$  by Stokes's theorem.

$$\iint_S A \cdot ds = \iiint_V (\nabla \cdot A) \cdot dV \Rightarrow$$

Volume  $V$  enclosed by the closed surface  $S$ , as shown in the above figure. The surface and volume integrals of the vector field  $A$ , are related through the divergence theorem.

Cartagena99


CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

Gradient theorem.

# Finite control Volume Approach





Finite control volume.  
Fixed in space with  
the fluid moving  
through it.



Finite control  
volume moving with  
the fluid such that the  
same fluid particles  
are always in the same  
control volume

# Infinitesimal Fluid Element Approach



Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

the local flow velocity

## Physical Meaning of the Divergence of velocity

The divergence  $\nabla \cdot \mathbf{v}$  is physically the time rate of change of the volume of a moving fluid element of fixed mass per unit volume of that element.

Consider a control volume moving with the fluid. This C.V. is always made up of the same fluid particles as it moves with the flow.  $V$  and control surface  $S$  are changing with time as it moves to different regions of the flow where different values of  $\rho$  exist.



Moving control volume used for the physical interpretation of the divergence of velocity at some instant time.

The change in the volume of the control volume  $\Delta V$  due to just the movement of  $ds$  over a time elemental  $\Delta t$ . It is equal to the volume of the long, thin cylinder with base area  $ds$  and altitude

$(\mathbf{v} \cdot \Delta t) \cdot \mathbf{n}$ ; that is

$$\Delta V = [(\mathbf{v} \cdot \Delta t) \cdot \mathbf{n}] ds$$

$$\Delta V = (\mathbf{v} \cdot \Delta t) d\mathbf{S} \rightarrow \text{vector.}$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

is equal to the summation of the above equation over the total control surface..

$$\oiint_S (\vec{v} \cdot \Delta \vec{t}) \cdot dS$$

If this integral is divided by  $\Delta t$ , the result is physically the time rate change of the control volume.

$$\frac{DV}{Dt} = \frac{1}{\Delta t} \oiint_S (\vec{v} \cdot \Delta \vec{t}) \cdot dS = \oiint_S \vec{v} \cdot d\vec{S} \quad \text{Applying the divergence theorem.}$$

$$\left[ \frac{DV}{Dt} = \iiint_V (\nabla \cdot \vec{v}) \cdot dV \right]$$

Think about if the control volume is very small

$\delta V$ .

$$\frac{D\delta V}{Dt} = \iiint_{\delta V} (\nabla \cdot \vec{v}) \cdot dV$$

$\nabla \cdot \vec{v}$  is essentially the same value throughout  $\delta V$ , thus the integral is approached to  $\nabla \cdot \vec{v} \cdot \delta V$

$$\frac{D\delta V}{Dt} = (\nabla \cdot \vec{v}) \delta V$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70


---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70



# Continuity Equation

Consider a given area  $A$  arbitrary oriented in a flow field. We are looking at an edge view of Area  $A$ . Let  $A$  be small enough such that the flow velocity  $V$  is uniform across  $A$ .



$$\text{Volume} = (Vn dt) A$$

The mass inside the shaded ~~area~~ volume is

$$\text{Mass} = \rho \cdot (Vn dt) \cdot A$$

$$\dot{m} = \frac{\rho (Vn dt) A}{dt}$$

$$\dot{m} = \rho Vn A$$

The mass flux, is defined as the mass flow per unit area.

$$\left[ \text{Mass flux} = \frac{\dot{m}}{A} = \rho Vn \right]$$

## Physical principle

Consider a flow field wherein all properties vary with spatial location and time.  $\rho = \rho(x, y, z, t)$

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

$$B = C$$



$\rho \vec{V}_n ds = \rho \vec{V} \cdot d\vec{s}$  Elemental mass flow across the area  $dS$  is, then

$B = \iiint_V \rho \vec{V} \cdot d\vec{s}$  the mass contained within the elemental volume  $dV$  is  $\rho dV$ . total mass is

$\iiint_V \rho dV$  the time rate of increase of mass inside  $V$  is then

$\frac{\partial}{\partial t} \iiint_V \rho dV$  The time rate of decrease of mass inside  $V$  is then

$-\frac{\partial}{\partial t} \iiint_V \rho dV = C$  as  $B$  must be equal to  $C$

$$\iiint_V \rho \vec{V} \cdot d\vec{s} = \frac{\partial}{\partial t} \iiint_V \rho dV$$

$$\left[ \frac{\partial}{\partial t} \iiint_V \rho dV + \iiint_V \rho \vec{V} \cdot d\vec{s} = 0 \right]$$

Conservation of mass to a finite control volume, fixed in space

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

$$\oint_V \frac{\partial \rho}{\partial t} dV + \oint_S \rho \vec{v} \cdot d\vec{s} = 0$$

Applying the divergence theorem.

$$\oint_S (\rho \vec{v}) \cdot d\vec{s} = \oint_V \nabla \cdot (\rho \vec{v}) dV$$

$$\oint_V \frac{\partial \rho}{\partial t} dV + \oint_V \nabla \cdot (\rho \vec{v}) dV = 0$$

$$\oint_V \left( \frac{\partial \rho}{\partial t} + \nabla \cdot (\rho \vec{v}) \right) dV = 0$$

$$\left[ \frac{\partial \rho}{\partial t} + \nabla \cdot (\rho \vec{v}) = 0 \right]$$

For incompressible flow and ~~un~~ steady flow.

$$\rho (\nabla \cdot \vec{v}) = 0 \quad \rho \neq 0$$

$$\nabla \cdot \vec{v} = 0 \Rightarrow \frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} = 0$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

## Momentum equation

Newton's second law is frequently written as

$$F = m\vec{a}$$

General form  $F = \frac{d}{dt}(m\vec{v})$ . for mass constant is reduced to above equation  $m\vec{v}$  is the momentum of a body of mass  $m$ .

Physical principle. Force = time rate of change of momentum.

$F$ : is the force exerted on the fluid as it flows through the control volume. This force comes from two sources

- 1) Body Forces; gravity, electromagnetic force
- 2.) Surface forces; Pressure and shear stress acting on the control surface  $S$ .

Consider  $(f)$  represents the body force per unit mass exerted on the fluid inside  $V$ . the body force on elemental volume  $dV$

$$\int_V \rho f dV$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

The elemental surface force due to pressure acting on elemental of area  $ds$  is

$[-Pds]$  where negative sign indicates that the force is in direction opposite of  $ds$ .

$$\text{Pressure force} = - \iint_S P ds$$

In a viscous flow, shear and normal viscous stresses also exert a surface force,  $F_{\text{viscous}}$ .

$$F = \iiint_V \rho F dv + F_{\text{viscous}} - \iint_S P ds$$

Consider the right side of the equation of Newton's second law. The time rate of change of momentum of fluid as it sweeps through the fixed volume is the sum of two terms.

Net flow of momentum out of control volume across surface  $S$   $\equiv \int_S$

Time rate of change of  $\equiv \frac{d}{dt}$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

$$\vec{G} = \oint_S (\rho \vec{V} \cdot d\vec{S}) \cdot \vec{V}$$

The flow has a certain momentum as it enters the C.V. and it has a different momentum as it leaves the C.V. (due in part to the Force)

$$\rho \vec{V} \cdot d\vec{S} = \text{mass of fluid.}$$

The momentum of the fluid in the elemental volume  $dV$  is

$$(\rho dV) \cdot \vec{V}$$

The momentum at any instant is

$$\oint_V \rho \vec{V} dV$$

The time rate of change due to unsteady & flow fluctuations is

$$H = \frac{\partial}{\partial t} \oint_V (\rho \vec{V}) dV$$

$$\frac{d}{dt} (m \vec{P}) = \sigma + H \Rightarrow \frac{\partial}{\partial t} \oint_V (\rho \vec{V}) dV + \oint_S (\rho \vec{V}) d\vec{S} \cdot \vec{V}$$

$$\frac{\partial}{\partial t} \oint_V (\rho \vec{V}) dV + \oint_S (\rho \vec{V}) d\vec{S} \cdot \vec{V} = - \oint_S p d\vec{S} + \oint_S \rho \vec{f} \cdot d\vec{S} + F_{\text{viscous}}$$

**Cartagena99**

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

$$-\oint_S P ds = -\iiint_V \nabla \cdot P dv$$

$$\iiint_V \frac{\partial (\rho \vec{v})}{\partial t} dv + \oint_S (\rho \vec{v} \cdot d\vec{s}) \vec{v} = -\iiint_V \nabla \cdot P dv + \iiint_V \rho f dv + F_{viscous}$$

$$\iiint_V \frac{\partial (\rho \vec{v})}{\partial t} dv + \iiint_V \vec{v} \cdot \nabla (\rho \vec{v}) dv = -\iiint_V \nabla P dv + \iiint_V \rho f dv + F_{viscous}$$

$$\iiint_V \frac{\partial \rho \vec{v}}{\partial t} + \vec{\nabla} \cdot (\rho \vec{v} \cdot \vec{v}) + \nabla P - \rho f + F_{viscous} = 0$$

$$\frac{\partial (\rho \vec{v})}{\partial t} + \nabla (\rho \vec{v} \cdot \vec{v}) = -\nabla P + \rho \vec{g} + F_{viscous}$$

$$\left[ \frac{D(\rho \vec{v})}{Dt} = -\nabla P + \rho \vec{g} + \mu \nabla^2 \vec{v} \right]$$

x-direction

$$\frac{\partial \rho u}{\partial t} + \nabla \cdot (\rho u \cdot \vec{v}) = -\frac{\partial P}{\partial x} + \rho g_x + \mu \left( \frac{\partial^2 u}{\partial x^2} + \frac{\partial^2 u}{\partial y^2} + \frac{\partial^2 u}{\partial z^2} \right)$$

y-direction

$$\frac{\partial \rho v}{\partial t} + \nabla \cdot (\rho v \cdot \vec{v}) = -\frac{\partial P}{\partial y} + \rho g_y + \mu \left( \frac{\partial^2 v}{\partial x^2} + \frac{\partial^2 v}{\partial y^2} + \frac{\partial^2 v}{\partial z^2} \right)$$

z-direction

$$\frac{\partial \rho w}{\partial t} + \nabla \cdot (\rho w \cdot \vec{v}) = -\frac{\partial P}{\partial z} + \rho g_z + \mu \left( \frac{\partial^2 w}{\partial x^2} + \frac{\partial^2 w}{\partial y^2} + \frac{\partial^2 w}{\partial z^2} \right)$$

**Cartagena99**

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

The logo for Cartagena99 features the text 'Cartagena99' in a stylized, blue, serif font. The text is set against a light blue, arrow-shaped background that points to the right. Below the text, there is a horizontal orange bar with a slight gradient and a drop shadow effect.

**CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70**


---

**ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP:689 45 44 70**



An application of the momentum equation.

- Drag of a 2-D body.



$U_1$  is uniform flow

$U_2$  is a function of  $y \Rightarrow U_2 = f(y)$ .

1. The pressure distribution over the surface  $abhi$

$$- \iint_{abhi} P \cdot ds$$

2. The surface force on  $def$  created by the presence of the body.

$$\text{Surface force} = - \iint_{abhi} P \cdot ds - R'$$



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP: 689 45 44 70

of the body. giving

force on the ~~action~~

$$\frac{\partial}{\partial t} \iiint_V \rho \vec{v} dV + \iint_S (\rho \vec{v} \cdot d\vec{s}) \vec{v} = - \iint_{abhi} P d\vec{s} - R^1$$

Assuming steady flow.

$$R^1 = - \iint_S (\rho \vec{v} \cdot d\vec{s}) \vec{v} + \iint_{abhi} P d\vec{s}$$

This is a vector equation. Consider again the control volume. Taking the x-component, noting that the inflow and outflow velocities  $u_1$  and  $u_2$ , the component of  $R^1$  is the aerodynamic drag per unit span  $D^1$ .

$$D^1 = - \iint_S (\rho \vec{v} \cdot d\vec{s}) u - \iint_{abhi} (P \cdot d\vec{s})_x$$

$(P \cdot d\vec{s})_x$  is the x component of the pressure force exerted on the elemental area  $d\vec{s}$  of the control surface

The boundaries of the C.V.  $abhi$  are chosen far away from the body such that  $P$  is constant along these boundaries. For constant pressure.

$$\iint_{abhi} (P \cdot d\vec{s})_x = 0$$

Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

- 1. The section ab, hi and def are streamlines of flow. Since by definition V is parallel to streamline and ds is perpendicular to the control surface, along these sections V and ds are perpendicular vector and hence  $V \cdot ds = 0$ . As a result the contribution of ab, hi and def to the integral is zero.
- 2. The cuts cd and fg are adjacent to each other. The mass flux out of one is identically the mass flux into the other.

$$\oiint_S (\rho V) ds = - \int_i^a \rho_1 u_1^2 dy + \int_h^b \rho_2 u_2^2 dy$$

Because V and ds being opposite direction along ai

Continuity equation

$$\oiint_S (\rho V) ds = - \int_i^a \rho_1 u_1 dy + \int_h^b \rho_2 u_2 dy = 0$$

$$\Rightarrow \int_i^a \rho_1 u_1 dy = \int_h^b \rho_2 u_2 dy \quad \text{multiplying } u_1$$

$$\int_i^a \rho_1 u_1^2 dy = \int_h^b \rho_2 u_2 dy$$



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70  
 ...  
 ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP: 689 45 44 70

$$\oint_S (\rho v \cdot ds) u = - \int_h^b \rho_2 u_2 u_1 dy + \int_h^b \rho_2 u_2^2 dy$$

$$\oint_S (\rho v \cdot ds) u = - \int_h^b \rho_2 u_2 (u_1 - u_2) dy$$

$$\left[ D^1 = \int_h^b \rho_2 u_2 (u_1 - u_2) dy \right]$$

$\rho_2 u_2$ : mass flux

$u_1 - u_2$ : velocity decrement at a given  $y$  location.

Decrement in momentum by  $(u_1 - u_2)$  and  $\rho_2 u_2$  mass flux that exits across the wake.

For incompressible flow.

$$\left[ D^1 = \rho \int_h^b u_2 (u_1 - u_2) dy \right]$$

Ex.

Consider on incompressible flow. laminar boundary layer growing along the surface flat plate. with chord length  $c$ . The thickness of the BL. at trailing edge.

$$\delta = \frac{5c}{\sqrt{Re}} \approx \frac{5c}{\sqrt{\rho U c \mu}}$$

Cartagena99


CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

assumony velocity profile through the boundary layer is given by power-law

$$u = V_{\infty} \left(\frac{y}{\delta}\right)^n$$



Calculate the value of n, consistent with the all information given above

$$C_f = \frac{D'}{\rho_{\infty} c} = \frac{\rho_{\infty}}{2 \rho_{\infty} V_{\infty}^2 c} \int_0^{\delta} u_2 (u_1 - u_2) dy$$

$$C_f = \frac{2 \rho_{\infty}}{\rho_{\infty}} \int_0^{\delta/c} \frac{u_2}{V_{\infty}} \left( \frac{u_1}{V_{\infty}} - \frac{u_2}{V_{\infty}} \right) d\left(\frac{y}{c}\right)$$

$$C_f = 2 \int_0^{\delta/c} \frac{u_2}{V_{\infty}} \left( 1 - \frac{u_2}{V_{\infty}} \right) d\left(\frac{y}{c}\right)$$

$$\frac{1.328}{\sqrt{Re_c}} = 2 \int_0^{\delta/c} \frac{V_{\infty}}{V_{\infty}} \left(\frac{y/c}{\delta/c}\right)^n \left[ 1 - \frac{V_{\infty}}{V_{\infty}} \left(\frac{y/c}{\delta/c}\right)^n \right] d\left(\frac{y}{c}\right)$$



CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP:689 45 44 70


$$\frac{1.328}{\sqrt{Re_c}} = \frac{2}{n+1} \left(\frac{\delta}{c}\right) - \frac{2}{2n+1} \left(\frac{\delta}{c}\right)$$

$$\frac{1.328}{\sqrt{Re_c}} = \frac{10}{n+1} \sqrt{\frac{1}{Re_c}} - \frac{10}{2n+1} \left(\sqrt{\frac{1}{Re_c}}\right)$$

$$\frac{1}{n+1} - \frac{1}{2n+1} = \frac{1.328}{10}$$

$$0.2656n^2 - 0.6036n + 0.1328 = 0$$

$$n=2 \text{ or } n=0.25$$



Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---


ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

# Energy Equation

Physical Principle: Energy can be neither nor destroyed:  
It can only change the form.

Consider a fixed amount of matter contained within a closed boundary. This matter defines the system. This system contains a certain amount of energy. The system contains a unit mass. (e) internal energy per unit mass.

surroundings



$$\delta q + \delta w = de \quad \text{1st Law of thermodynamics.}$$

We apply the 1st Law to the fluid flowing through the fixed control volume.

$$B_1 + B_2 = B_3$$

$B_1$  = rate of heat added to fluid inside C.V. from surrounding.



**CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE**  
**LLAMA O ENVÍA WHATSAPP: 689 45 44 70**

---

**ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS**  
**CALL OR WHATSAPP: 689 45 44 70**

$B_1 =$  This can be visualized as volumetric heating of the fluid inside C.V. due to the absorption of radiation originating outside the system

- mass contained within a elemental volume is  $\rho dV$ .

- rate of heat addition to this mass is  $\dot{q}(\rho dV)$

$$\text{Rate of volumetric heating} = \iiint \dot{q} \rho dV$$

Note! If flow is viscous. Heat can be transferred into C.V. by means of thermal conduction and mass diffusion across the C. surface.

$$B_1 = \iiint \dot{q} \rho dV + \dot{Q}_{\text{viscous}}$$

Rate of doing work on moving body =  $F \cdot \vec{V}$ ; This

result leads to an expression for  $B_2$ . Consider a  $ds$  area of the control surface. Pressure force on this elemental area is  $P ds$ . The work due to this force

$$\text{is: } = (P ds) \vec{V}$$

Rate of work done on fluid inside Volume due to Pressure force on C.

$$= - \iint (P ds) \vec{V}$$

**Cartagena99**

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70



Consider the elemental volume  $dV$  inside control volume.  $f$  is the body force per unit mass. Rate of work done on the elemental volume due to the body force  $(\rho f dV) \cdot \vec{v}$ .

Rate of work done on fluid inside  $V$  due to body forces =  $\iiint_V (\rho f dV) \cdot \vec{v}$

Note: If the flow is viscous, the shear stress on the control ~~surface~~ (surface) will also perform work on the fluid as it passes across the surface.

$$\dot{B}_2 = - \oint_S (P ds) \vec{v} + \iiint_V (\rho \vec{f} \cdot \vec{v}) dV + \dot{W}_{viscous}$$

To visualize the energy inside the control volume, the internal energy ( $e$ ) is due to the random motion of atoms and molecules inside the system. Applying the 1st Law for open system, it needs to consider the kinetic energy. the total energy  $e + \frac{v^2}{2}$

Net rate of flow of total =  $\oint (\rho \vec{v} ds) \cdot (e + \frac{v^2}{2})$

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70



If flow is unsteady, there is a time rate of change of total energy inside the control volume, due to the transient fluctuations of the flow-field variables.

Total energy in elemental volume  $dV$  is  $\rho(e + \frac{V^2}{2})dV$   
 The complete energy inside C.V. at any instant in time is

$$\iiint_V \rho(e + \frac{V^2}{2}) dV$$

Time rate of change of total energy inside  $V$  due to transient variations of flow-field variables

$$= \frac{\partial}{\partial t} \iiint_V \rho(e + \frac{V^2}{2}) dV$$

$$B_3 = \frac{\partial}{\partial t} \iiint_V \rho(e + \frac{V^2}{2}) dV + \iint_S (\rho \vec{V} \cdot d\vec{s}) (e + \frac{V^2}{2}) dA$$

$$\iint_V \dot{q} \rho dV + \dot{Q}_{viscosos} = \iint_S P \cdot \vec{V} \cdot d\vec{s} + \iiint_V P(\rho) \vec{V} dV + \dot{W}_{viscosos} =$$

$$\frac{\partial}{\partial t} \iiint_V \rho(e + \frac{V^2}{2}) dV + \iint_S (\rho \vec{V} \cdot d\vec{s}) (e + \frac{V^2}{2})$$

**Cartagena99**

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP: 689 45 44 70

$$\int_V \left( \frac{\partial}{\partial t} \left[ \rho \left( e + \frac{V^2}{2} \right) \right] + \nabla \cdot \left[ \rho \left( e + \frac{V^2}{2} \right) \vec{V} \right] + \dot{q} \rho dV - \nabla \cdot (P \vec{V}) + \rho (f \cdot \vec{V}) + \dot{Q}_{\text{viscous}} + \dot{W}_{\text{viscous}} \right) dV \quad (18)$$

For steady steady, inviscid flow and adiabatic we obtain

$$\oint_S \rho \left( e + \frac{V^2}{2} \right) \vec{V} \cdot d\vec{s} = - \oint_S P \vec{V} \cdot d\vec{s} + \rho (f \cdot V)$$

For  $f=0$ ; we obtain. 
$$\oint_S \rho \left( e + \frac{V^2}{2} \right) \vec{V} \cdot d\vec{s} = - \oint_S (P \vec{V} \cdot d\vec{s})$$

we obtain 
$$\nabla \cdot \left[ \rho \left( e + \frac{V^2}{2} \right) \vec{V} \right] = - \nabla \cdot (P \vec{V})$$

Energy equation. For incompressible flow, thermal conductivity constant

$$\rho c_p \frac{DT}{Dt} = \kappa \nabla^2 T + \Phi$$

where  $\Phi = \mu \left( \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right) \frac{\partial u_i}{\partial x_j} + \lambda \left( \frac{\partial u_i}{\partial x_i} \right)^2 \quad \lambda = -\frac{2}{3} \mu$

$$\Phi = \mu \left[ \left( \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \right) \frac{\partial u}{\partial x} + \left( \frac{\partial v}{\partial x} + \frac{\partial u}{\partial y} \right) \frac{\partial v}{\partial y} + \dots \right]$$

**Cartagena99**

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
LLAMA O ENVÍA WHATSAPP: 689 45 44 70

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
CALL OR WHATSAPP: 689 45 44 70

$$+ \lambda \left( \frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} \right)^2$$

$$\Phi = \mu \left[ 2 \left( \frac{\partial u}{\partial x} \right)^2 + 2 \left( \frac{\partial v}{\partial y} \right)^2 + 2 \left( \frac{\partial w}{\partial z} \right)^2 + \left( \frac{\partial v}{\partial x} + \frac{\partial u}{\partial y} \right)^2 + \left( \frac{\partial w}{\partial y} + \frac{\partial v}{\partial z} \right)^2 + \left( \frac{\partial u}{\partial z} + \frac{\partial w}{\partial x} \right)^2 \right] + \lambda \left( \frac{\partial u}{\partial x} + \frac{\partial v}{\partial y} + \frac{\partial w}{\partial z} \right)^2$$



Cartagena99

CLASES PARTICULARES, TUTORÍAS TÉCNICAS ONLINE  
 LLAMA O ENVÍA WHATSAPP: 689 45 44 70

---

ONLINE PRIVATE LESSONS FOR SCIENCE STUDENTS  
 CALL OR WHATSAPP: 689 45 44 70